

Fitting Instructions: AUD04H

Vehicle: AUDI Q5/SQ5 (2018)

Towing Capacity: 2000 / 200Kgs

Fitting Kit: 2x D shackles
2x Towbar Rating Labels

1.	Remove 4 screws base of bumper fascia using T25 torx bit.
2.	Plastic wheel trim around wheel arch must be removed which is clipped in position, locate 3 torx screws located vertically in the upper area behind wheel well liner and 1 screw located behind wheel well trim either side remove with T25 torx bit.
3.	Open tail gate and remove 2 plastic bumper holding screws (1 either side) using T25 torx bit.
4.	Remove cargo area flooring and rear panel surrounding lock area, this is clipped into position.
5.	Remove rubber grommets located in boot area back panel (1 ether side), use 10mm tube socket to remove bumper holding nuts.
6.	Remove passenger side interior panel, disconnect 2 wiring harnesses and push out rubber grommet, feed out to rear bumper. Using 10mm socket remove bumper holding nut, repeat on driver side.
7.	Remove rear bumper bar.
8.	Remove & discard Crash Support Panel retaining mounting hardware.
9.	Mount towbar to rear of car using bolts removed in previous step.
10.	Ensure towbar is central & tighten all bolts.
11.	Note: Bumper cut as per diagram 50mm either side of centre. DO NOT CUT WIRE BEHIND CENTRE FASCIA.
12.	Refit items removed in steps 1 - 7.
13.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.

