



Fitting Instructions:

HOL025H & HOL026H

Vehicle: Holden Colorado / Isuzu Demax - Ute with bumper (06/2012 – ON)

Holden Colorado / Isuzu Demax - Tray (06/2012 – ON)

Towing Capacity: 3500kg

Fitting Kit: 6x M12 x 1.25 x 40 bolts, spring & flat washers

2x 'D' shackles

2x Towbar Rating Labels

1.	Bumper model only Remove Bumper retaining bolts (3 either side). Support bumper if required. Note: Towbar fits to outside of bumper support arms.
2.	Mount tow hitch to chassis aligning holes in towbar with existing holes in chassis / bumper. Using M12 x 40 bolts, spring & flat washers supplied. Do not tighten bolts at this stage.
3.	Bumper model only Check bumper alignment.
4.	Tighten all bolts (6)
5.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.