

## Fitting Instructions: LEX01H

**Vehicle:** LEXUS RX350 WAGON 01/2016 - ON

**Towing Capacity:** 1500/150 Kg's

**Fitting Kit:**

- 8x M12 x 40 bolts, star & flat washers
- 2x D shackles
- 2x Towbar Rating Labels

### ECM Required to wire this vehicle

1.	Remove rear tie down brackets. (Both sides)
2.	Remove plastic plugs from both passenger and drivers side of rear subframe.
3.	Mount Tow Hitch to original holes using 12mm bolts, complete with star and flat washers
4.	Tighten all bolts.
5.	Apply Towbar Rating Labels to driver's side door sill and non-removable part of the towbar.