



## Fitting Instructions: **HOL025H & HOL026H**

**Vehicle:** Holden Colorado / Isuzu D max - Ute with bumper ( 06/2012 – ON )

Holden Colorado / Isuzu D max - Tray ( 06/2012 – ON )

**Towing Capacity:** 3500kg

**Fitting Kit:** 6x M12 x 1.25 x 40 flange bolts

2x 'D' shackles

2x Towbar Rating Labels

1.	<b>Bumper model only</b> Remove Bumper retaining bolts (3 either side). Note: Bumper bar holding brackets will move from original position, when installing tow hitch, brackets must be realigned with original holes. <b>Note:</b> Towbar fits to outside of bumper support arms.
2.	Mount tow hitch to chassis aligning holes in towbar with existing holes in chassis / bumper. Using M12 x 40 bolts supplied. Do not tighten bolts at this stage.
3.	<b>Bumper model only</b> Check bumper alignment.
4.	Tighten all bolts (6)
5.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.